

# Standard Operating Procedure: New Media and Color Profile Setup

**Document ID:** SOP-C4-001

**Objective:** To provide a comprehensive, step-by-step guide for creating, calibrating, and implementing a new media print condition on the EQUIOS printing system.

---

## 1.0 Print Condition Creation and Configuration

This phase covers the initial setup of the new media profile, including its core settings and associated calibration files.

### 1.1 Create the Core Print Condition

1. Navigate to the desired paper stock within the media library.
2. From the **Add Menu**, select **Create New Print Condition**.
3. In the configuration window, set the following parameters:
  - **Base Profile/Template:** Select **NextIJ**.
  - **Printer Resolution:** Choose the appropriate resolution for the intended job.
4. Enter a unique and descriptive name in the **Print Condition Name** field.
5. **Critical Step:** Copy the full Print Condition name to the clipboard (**Ctrl+C**). This name will be used for all associated profiles to ensure consistency.

### 1.2 Generate Supporting Calibration Profiles

*Note: The following profiles must be created using the exact name copied in step 1.1.5.*

1. **Alignment Profile:** Navigate to the **Alignment** tab, initiate a new profile based on **NextIJ**, and paste the copied name.
2. **Uniformity Profile:** Navigate to the **Uniformity** tab, initiate a new profile based on **NextIJ**, and paste the copied name.
3. **ICC Preset:** Navigate to the **ICC Preset** tab, initiate a new preset, and paste the copied name.

### 1.3 Define Media Attributes

With the new Print Condition selected, define its physical and operational parameters.

- **Paper Description:**
  - **Brand:** Manufacturer of the paper.
  - **Weight:** Paper weight (e.g., g/m<sup>2</sup> or lbs).
  - **Type:** Paper finish (e.g., Gloss, Matte, Coated, Uncoated, Offset).

- **Resolution and Speed:** Confirm the print modes are correct.
  - 1200 x 1200 dpi @ 50 mm/s
  - 1200 x 600 dpi @ 100 mm/s
  - 600 x 600 dpi @ 120 or 150 mm/s
- **Roll Width:** Enter the width of the paper roll.
- **Paper Thickness:** Use a micrometer to obtain an accurate measurement in millimeters (mm) and enter the value.
- **Special Settings:** Configure any unique media properties, such as pre-printed areas or registration holes.

#### 1.4 Activate and Register the Print Condition

1. **Activate:** Review all settings for accuracy. Click the **Make Current** icon (e.g., a checkmark or star) next to the new Print Condition name.
2. **Register in Jet Inspect:**
  - Access **Service Mode:** Navigate to **System Settings** and change the user to **Service** (Password: **SCREEN**).
  - Open the **Jet Inspect** application and select the **Register** icon (upper right) to register the new media profile.

---

## 2.0 System Calibration

This phase involves calibrating the printer's physical output to the newly created media profile.

### 2.1 Perform Print Head Alignment

1. Navigate to the **Print Head Alignment** menu.
2. Select **Print and Adjust** to launch the automated alignment wizard.
3. Ensure all color channels are selected and uncheck the **Print Test** option.
4. Select the **High Speed Alignment** button to proceed.
5. To verify the results, select **Edit** from the top of the window and print a test pattern.
6. If the test print reveals misalignment, perform manual adjustments as necessary.

### 2.2 Calibrate Print Density and Linearization

- **2.2.1 Mid-Tone Density Linearization**
  1. Navigate to the **Print Density Adjustments** menu. In the **Mid-Tone Adjustment** section (middle panel), select **Print and Adjust** to generate a density chart.

2. Launch the **LinearizationTool** on the EQUIOS Center PC (use Remote Desktop if necessary).
  3. Select the new Print Condition and measure the printed chart for **Printer 1 (Front)**. Enter the values for the recommended points: **0, 10, 30, 50, 70, 100%**.
  4. Save the file, appending **\_P1** to the name.
  5. Repeat the measurement and saving process for **Printer 2 (Back)**, appending **\_P2**.
- **2.2.2 Apply Mid-Tone Correction Data**
    1. Return to the **Mid-Tone Adjustment** window on the printer panel.
    2. Press the **Mid-tone density correction rollback** button.
    3. Select the **\_P1** linearization file and press **Rollback**.
    4. Repeat the process for the **\_P2** file. Exit when complete.
  - **2.2.3 Set Maximum Densities (D-Max)**
    1. In the **Print Density Adjustments** menu, go to the **Max Densities** section (top panel) and select **Print and Adjust** to output the D-Max chart.
    2. Measure the chart and adjust the values to meet the targets based on the *Paper Evaluation Results (TPJ520 HD for SC ink)*.

Paper Type	Black	Cyan	Magenta	Yellow
Coated	1.65 - 1.70	1.50 - 1.55	1.45 - 1.50	1.00
Uncoated	1.20 - 1.25	1.05 - 1.10	1.00 - 1.05	0.80 - 0.85

## 2.3 Adjust Print Uniformity

1. Navigate to the **Print Uniformity** menu and select **Print and Adjust**.
2. Choose the **High Speed Uniformity** option.
3. Select **No** for the **Intelligent Nozzle Control** prompt.
4. Confirm the temperature setting by clicking **OK**.
5. *Note: For optimal results on Gloss and Matte papers, this process should be run at least twice.*

---

## 3.0 ICC Profile Generation and Implementation

This phase finalizes the color characterization of the media by creating and assigning an ICC profile.

### 3.1 Configure Final Print Settings

1. **Set AIA (Advanced Ink Amount):** In the **Print Density Adjustment** menu, set the AIA value based on paper type and **Save** the changes.

- **Offset/Uncoated:** 130% - 140%
  - **Coated:** 140% - 160%
2. **Print ICC Profiling Chart:** From the bottom of the **Print Density Adjustment** window, output the **CMYK 1617** patch chart.

### 3.2 Measure and Process Chart Data (ColorAnt)

1. Open the **ColorAnt** application.
2. Drag and drop the **CMYK 1617** measurement data file (.txt) into the window.
3. Select **Measure**, connect the spectrophotometer, and click **Start**.
4. Once measurement is complete, close the reading window and select **Transfer and Exit**.
5. Process the data using the following tools in order: **Redundancies** (ensure "Remove Duplicate Patches" is checked), **Corrections**, and **Smooth**.
6. Navigate to **File > Save As** and save the processed data as a .txt file with a descriptive profile name.

### 3.3 Generate ICC Profile (CoPra)

1. Open the **CoPra** software.
2. Click **New Color Profile**, then **Load**.
3. Select the .txt file saved from ColorAnt and click **Open**.
4. Proceed by clicking **Next**, using the default screen settings, and save the final **.icc profile**.

### 3.4 Implement the New Profile

1. **Assign Profile in Media DB Manager:**
  - Open the **Media DB Manager** and select **New Profile**.
  - Assign the newly generated ICC profile to the corresponding Paper ID.
  - Click **Next**, then **Register** to finalize the assignment. Close the application.
2. **Update EQUIOS Template:**
  - Open the **EQUIOS Client** and navigate to the **Paper Evaluation Job Template**.
  - Change the **Print Conditions** to the new profile.
  - Save the changes and register the Paper Evaluation PDF to complete the setup.

---

## 4.0 Verification (Optional)

This optional phase verifies the calibration against G7 grayscale standards.

### 4.1 G7 Grayscale Calibration and Verification

1. Open the **Curves** software.
2. From the top menu, navigate to **Calibrate > Untitled Calibration**.
3. Select **Run1 Calibration**.
4. Under the **Based on Measurements** section, select the **Measure Chart** icon to initiate a measurement.

\* Load the **P2P251** chart and measure it using the connected spectrophotometer (e.g., MYIRO-9).

\* Once complete, analyze the resulting curve to verify if it meets G7 grayscale specifications.

\* **If the curve fails validation:** A corrective **Press Curve** can be created in **EQUIOS Color Tools**.